lefreQue
pure sound better tuning

Universal Manual IntoniQue
for Woodwinds & Brass


SA


SE


MC


MA


SA

All flutes (you can use a small rubber ring at the end of the footjoint to prevent that the intoniQue can fall off)


SE

Piccolo


MA

Euphonium, All tubas, Sousaphone


SA

All saxophones, alto- and bass clarinets

Q-Boosters




MC

Bb and A clarinets


SA

All trumpets, Bugle, Cornet,
Trombone, French-horn, Euphonium

The thick magnet is always the projection side of the IntoniQue.

For instruments with bell, this is the inside of the bell.

For piccolo and flute, place the thick side on the outside of the tube!

Always open the IntoniQue first before placing it on the instrument. Also open it again before moving it! This is to prevent scratches!

IntoniQue is not available for Oboe and Bassoon (yet)

www.lefreQue.com